



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA325P.

FORD Transit Van (VN & VO)

1. The cabin air filter is located behind the glove box compartment.
2. Open the glove box and empty it of any stored items, it will make the job easier. Press in both top front corners and pull down the lid until it completely unhinges and is able to open all the way.
3. The cabin air filter can be seen at this point. Identify the lid and proceed to open it by pressing the release tab on the corner.
4. Slide the old cabin air filter out and clean the area from any accumulated debris.
5. Insert the new cabin air filter facing in the correct air flow direction as indicated on the filter.
6. Refit all components in reverse order.

GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

GUD Automotive -
A division of GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz