

FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA320C.

BMW 3 Series (F3x)

Also fits: BMW 2 Series (F 2x) & 4 Series (F3x) 1 Series (F2x)

1. The cabin air filter is located in the passenger footwell right below the glove box compartment.
2. Slide the passenger seat to the maximum furthest position to allow for space. Get yourself in the footwell area and identify plastic trim covering off the area behind the glovebox unit.
3. To remove the trim use a 10mm socket to remove both bolts holding it together. Grab the trim from the top front section and gently pull to unclip it and disconnect both footwell light connectors.
4. Once the trim cover is removed, look out for the cabin air housing (see pic below) you will need a T20 Torx screw driver to undo the 2 screws securing the housing lid. Remove the screws and pull down the lid then rest it on the footwell.
5. Slide out the old cabin air filter, clean the area of any accumulated debris and insert the new cabin air filter in the right air flow direction as indicated on the filter.
6. Refit all components in reverse order.

