



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA301C.

MERCEDES BENZ A Class (W168)

1. The cabin air filter is located in the engine cowl.
2. Open the bonnet of the vehicle and remove the 7 screws holding the cowl plastic trim. Close the bonnet and pull the plastic trim out, start from one corner and gradually move to the opposite corner.
3. Remove both wiper arms and then remove the screws holding the plastic trim from both sides (2x screws) and pull the trim out.
4. Open the bonnet to better access the cabin air filter. Slide the old filter out and clean the area from any accumulated debris.
5. Insert the new cabin air filter ensuring it is facing in the correct air flow direction as indicated on the filter.
6. Refit all components in reverse order.

Ryco Group Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia
www.rycofilters.com.au

RYCO Group
A division of GUD NZ Holdings Ltd
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz