

1. The cabin air filter is located in the centre console behind the lower trim in the passenger footwell area.

2. For better working space, slide the passenger seat all the way back. Leave the glove box shut and remove the four (4) bottom screws securing the compartment. Open the glove box and remove the remaining three (3) screws at the top.

3. Gently pull out the compartment until the light connector is visible and disconnect. Continue with the compartment removal.

4. Identify the cabin air filter housing and unclip the lid. Slide out the old cabin air filter carefully to avoid any accumulated debris from being spread around.

5. Slide in the new filter making sure it faces the correct air flow direction and refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz