



How to clean and condition your Ryco O₂Rush Performance Air Filter



Recommended Personal Protection Equipment (PPE):
Latex gloves and glasses should be used when cleaning and conditioning the filter.

CLEAN + CONDITION = REUSE

Step 1. Cleaning your Ryco Foam Air Filter Using RFA109: Ryco Foam Filter Cleaner

1. Remove the foam from the filter.
2. Apply 50-100ml of cleaner directly onto the foam. Alternatively, it can be applied using a spray bottle.
3. Massage the foam until the suds form and take on the colour of the dirt.
4. Dip the foam into clean water, continue to massage until residual dirt and conditioner are fully rinsed.
5. Rinse at least 3 times with clean water until all the cleaner is washed out.
Do not leave to soak.
6. Dry thoroughly with a cloth and allow to air dry until all moisture has been removed.

Step 2. Conditioning your Ryco Foam Air Filter Using RFA108 Ryco Foam Filter Conditioner

1. Ensure the filter is completely dry from washing before applying the filter conditioner.
2. Warm the conditioner by placing in a bowl of hot water for a few minutes.
3. Pour the warm conditioner into a plastic bag, container or bucket and add the filter.
4. Work the conditioner into foam by **folding** then firmly **squeezing** leaving no dry areas.
Only a slight residue of conditioner should remain on your fingers when pinching the foam.
Excess conditioner can be poured back into the bottle and reused.

NOTE: Do not wring or twist the foam to remove the conditioner.

5. Wrap the filter tightly in a cotton rag for 20 minutes to draw remaining excess liquid.
6. Refit the filter.

Maintenance Tips

The durability of the expanded open cell polyurethane foam the filter is made from means it can be serviced many times over.

- **Never soak** the filter in cleaner fluid
- **Dry thoroughly** prior to conditioning
- Don't let the foam filter dry out between services
- When conditioning simply squeeze the fluid out - never wring or twist the media
- For use on **Ryco Foam Filters** only
- SDS available at rycofilters.com.au/performance



Recommended service interval is 15,000 km's or 12 months whichever comes first.
The more regularly the air filter is serviced using Ryco cleaner and conditioner the longer it will last.

Australia
Ryco Group Pty Ltd
29 Taras Avenue, Altona North
Victoria 3025 Australia
www.rycofilters.com.au

New Zealand
Ryco Group
A division of GUD NZ Holdings Ltd
626A Rosebank Rd, Avondale
Auckland, New Zealand
www.ryco.co.nz

Social Networks
Facebook: www.facebook.com/rycofilters
YouTube: www.youtube.com/rycofilters1
Twitter: www.twitter.com/Ryco_Filters