

FITTING INSTRUCTIONS FOR RYCO FUEL FILTER 2756.

SUITS : CITROEN, FIAT, FORD, MAZDA, MINI, PEUGEOT, SUZUKI, VOLVO FILTER LOCATED IN ENGINE BAY, BACK RIGHT CORNER.



1: Fuel injection system elements in diesel engines are made with very strict tolerances and very little slackness. For this reason cleanliness is absolutely necessary during operating these elements.



2: Remove engine masking frame (A), disconnect air filter casing (B)




3: Remove electric connector of fuel heater (A), disconnect the quick connects of fuel filter pipes (B).



4: press filter safety mandrel, take filter out.



5: Remove heater element from used filter in direction shown in the drawing



6: Remove safety plug from new filter.



7: Install fuel heater element in new filter.



8: Install filter in seat, remove safety, plugsconnect fuel pipes (A), connect heater connector (B).



9: Pump the fuel with manual pump until resistance is felt.



10: Install air filter casing, connect flow meter, start engine, check system for leakage.



11: Fix engine masking frame.



AUSTRALIA

GUD Automotive Pty Ltd 29 Taras Avenue, Altona North Victoria 3025 Australia. www.rycofilters.com.au

NEW ZEALAND

GUD Automotive - A division of GUD (NZ) Holdings Limited 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz

SOCIAL NETWORKS

Facebook: http://facebook.com/rycofilters YouTube: http://youtube.com/rycofilters1 Twitter: http://twitter.com/Ryco_Filters