


RYCO FILTERS



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA356C.



1. The cabin air filter is located behind the glove box compartment on the passenger side. To remove, unscrew tabs underneath glove box and pull off the panel that becomes loose.
2. Pull open panel on the window side of the glove box, you should find an electrical connector. disconnect this electrical connector.
3. Now the glove box compartment needs to come off. Open up the glove box and remove all 4 screws and pull the compartment out from the top section.
4. Now the cabin air filter housing is accessible. The cabin air filter housing is located behind where the glove box compartment was located. the front flap of the cabin air filter housing needs to be removed. to do so, remove all screws on the front of the flap then pull the front flap in a way that allows the tabs on the flap which connect it to the cabin air filter housing to unclip from the housing.
5. Remove and slide out the old cabin filter carefully to avoid accumulated debris from spreading around. Clean the area and slide in the new cabin air filter making sure it is facing in the right air flow direction indicated on the filter. Refit all components in reverse order.

RYCO Group Pty Ltd
29 Taras Avenue
Altona North, Victoria 3025
Australia
www.rycofilters.com.au

RYCO Group
A division of GUD NZ Holdings Ltd
626A Rosebank Road
Avondale, Auckland, New Zealand
www.ryco.co.nz