

1. The cabin air filter is located behind the glove box compartment unit on the passenger side. To gain access the unit is required to be removed.

2. With the glove box in a closed position unclip the side panel facing the door by pulling from the bottom section. Open the glove box and go back to the cavity left by the previously removed panel and identify the screw securing the top section of the glove box compartment and remove it then proceed to remove the 3 screws located in the top section of the compartment.

3. Refer to the footwell area and identify the plastic trim panel below the compartment and remove the three (3) screws securing it. After removing the trim remove the last remaining screw. The glove box compartment is now loose and can be pulled out. Start by pulling gently until the light connector is visible. Now disconnect the light connector and pull the unit out completely.

4. The cabin air filter housing is located right above the blower fan. Unclip the lid and grab the old cabin air filter, slide out carefully to avoid any accumulated debris from being spread around and clean the area.

5. Slide in the new cabin air filter making sure it is facing to the right air flow direction and refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz