



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA304P.

SSANGYONG Stavic

1. The cabin air filters are located behind the glove box compartment.

2. Open the glovebox and empty it of any stored items, it will make the job easier. Remove the 2 inner tabs located inside the glovebox on each top corner to unhinge the lid so it is able to open it fully.

3. Identify the cut open section in the back panel, the cabin air filter housing is in there. There are two different ways to open the housing, by pulling the cover out or by removing a couple screws.

4. Slide the old cabin air filters out, one at a time, and clean the area of any accumulated debris.

5. Insert the new cabin air filters facing in the correct air flow direction as indicated on the filters.

6. Refit all components in reverse order.

Ryco Group Pty Ltd 29 T aras Ave Altona North Victoria 3025 Australia. www .rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www .ryco.co.nz