

1. The cabin air filter is located behind the glove box compartment and it will have to be removed so it can replaced.

2. Open the glove box and from both top corners press inwards to bypass the retaining lugs so it can swing open completely.

3. The housing is now fully accessible. Press on both corners of the housing lid so it can be unclipped.

4. Grab the old filter and slide it out carefully to avoid any accumulated debris from spreading around. Insert the new filter making sure it is facing in the right air flow direction indicated on the filter. Refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave, Altona North Victoria 3025 Australia. www.rycofilters.com.au Ryco Group A Division of GUD NZ Holdings Ltd 19 Bell Ave, Otahuhu, Auckland New Zealand www.ryco.co.nz