

1. The cabin air filter is located behind the glove box compartment. To gain access to the cabin air filter it is required to be removed.

2. For better working space, slide the passenger seat all the way back. Open the glove box identify the strut on the outer side panel of the compartment facing the door. Unclip by pulling the bottom section of the strut. Note: Some may have a screw that will need to be undone.

3. Press inwards both top corners of the box and let the unit drop. Identify the cabin air filter housing and unclip the lid from one of the sides and remove. Slide out the old cabin air filter carefully to avoid any accumulated debris from being spread around.

4. Slide in the new filter making sure it faces the correct air flow direction. Refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz