

1. The cabin air filter is located behind the glove box compartment, it will have to be removed to gain access to the cabin air filter.

2. Open the glove box and press inwards on both top corners so that the retaining lugs can be bypassed then, let the compartment drop completely, unhinge and carefully remove.

3. Identify the cabin air filter housing and unclip both middle section clips then, unclip the bottom section one from the lid.

4. Grab and slide out the old cabin air filter carefully to avoid any accumulated debris from becoming spread around. Clean the area and insert the new filter making sure it is facing in the right air flow direction. Refit all components in reverse order.

RYCO Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group -A division of GUD (NZ) Holdings Limited 19 Bell Avenue, Otahuhu, Auckland, New Zealand www.ryco.co.nz