

1. The cabin air filter Is located in the engine bay below the windscreen on the passenger side.

2. Remove both wiper blades, open bonnet and remove screws holding plastic trim covering the cowl, put aside the gasket running in parallel to the cowl trim.

3. To remove the cowl trim completely, the wiper blade nuts must be removed. Remove the trim and the filter housing will be spotted under the passenger side wiper blade mechanical arm link.

4. Remove and clean out any accumulated debris from the housing and fit new cabin air filter making sure it is in the right air flow direction. Refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz