


# RYCO FILTERS



## PLUG USAGE INSTRUCTIONS FOR RYCO OIL FILTER R2722P

**USE PLUGS TO PREVENT DUST, DIRT ETC ENTERING  
INLET AND OUTLET HOUSING PORT  
WHEN HOUSING CAP IS DISCONNECTED.**



Ryco Group Pty Ltd  
29 Taras Ave Altona North  
Victoria 3025 Australia.  
[www.rycofilters.com.au](http://www.rycofilters.com.au)

RYCO Group  
A division of GUD NZ Holdings Ltd  
626A Rosebank Road Avondale  
Auckland, New Zealand