

TOOL BOX = PHILLIPS HEAD & STANDARD SCREW DRIVER.

- 1: Open bonnet, remove 2 nuts retaining the vacuum cannister to the cowl panel, remove cannister to safe position.
- 2: Remove used filter from filter housing and put in rubbish bin.
- 3: Install new RYCO filter into housing making sure to align ribs on filter with the grooves in housing.
- 4: Replace vacuum cannister.

Ryco Group Pty Ltd 29 Taras Ave, Altona North Victoria 3025 Australia. www.rycofilters.com.au Ryco Group A Division of GUD NZ Holdings Ltd 626A Rosebank Road, Avondale Auckland New Zealand www.ryco.co.nz