

1. The cabin air filter is located in the engine bay below the windscreen.

2. Open the bonnet and remove the plastic trim in the middle section (located near the windscreen) by unclipping it.

3. Slide out the old cabin air filter carefully to avoid any accumulated debris from spreading around.

4. Clean the area and slide in the new filter making sure it is facing to the right air flow direction and refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz