

RCA223M - HONDA LEGEND KB

FILTER IS LOCATED BEHIND THE GLOVE BOX

WORK PROCEDURE

- 1 The cabin air filter is located behind the glove box in the passenger side. The glove box will have to be removed to access the filter housing.
- 2 Open the glove box and press to the inside each of the rear top corners to release the retaining lugs then remove the strut on the left side by pulling the bottom bit to the outside.
- 3 Once the retaining lugs have been bypassed, drop or remove completely the unit. The cabin air filter housing will be right at the top of the blower. Unclip the housing lid from both sides.
- 4 Slide the old filter out carefully to avoid accumulated debris spreading around. Clean area and insert the new filter making sure it is in the right air flow direction. Refit all components in reverse order.




FIGURE 1