

1. The cabin air filter is located below the glove box in the passenger side towards the centre console.

2. Identify the plastic trim located below the glove box unit in the footwell area. Pull down the plastic division closest to the firewall and to the right, the cabin air filter housing will be visible.

3. Unclip the housing lid from the bottom and pull out. Reach for the filter and remove carefully to avoid accumulated debris from being spread around.

4. Clean area and insert the new filter making sure it is in the right air flow direction. Refit all components in reverse order.

RYCO Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group -A division of GUD (NZ) Holdings Limited 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz