

RYCO FILTERS



FITTING INSTRUCTIONS FOR RYCO CABIN AIR FILTER RCA426M MG.3

Filter is located behind glove box



1. The cabin air filter housing is located behind the glovebox. To gain access, the glovebox must be opened and lowered.



2. Release the glove box upper clips by pushing the upper glovebox inboard as shown in the diagram. The glovebox will lower on its hinges.



3. With the glove box lowered the filter housing can be accessed. Remove the housing cover and remove the existing filter. Remove and clean any remaining debris in the housing.



4. Insert the new filter into the housing. The UP arrow indicates the position direction. Refit all components in reverse order.

RYCO Group Pty Ltd
29 Taras Ave Altona
North Victoria 3025
Australia
www.rycofilters.com.au

RYCO Group- A division of
GUD (NZ) Holdings Limited.
19 Bell Avenue, Otahuhu,
Auckland 1060, New Zealand
www.ryco.co.nz