

1. The cabin air filter is located in the centre console at the front of the passenger foot well area.

2. Remove the cabin air filter housing cover. Remove the old cabin air filter. Remove any remaining debris in the cabin air filter housing.

3. Install the new cabin air filter. Ensure the flow arrow is pointing to the rear of the vehicle.

4. Refit all components in reverse order.

GUD Automotive Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au GUD Automotive -A division of GUD (NZ) Holdings Limited 19 Bell Avenue Otahuhu Auckland 1060, New Zealand www.ryco.co.nz