

1. The cabin air filter is located behind the glove box compartment. To gain access it is required to be removed.

2. For better working space, slide the passenger seat all the way back. Open the glove box, remove both top corner retaining lugs from the inside of the box so the lid can be dropped completely.

3. Identify the cabin air filter housing and unclip the lid from the sides and remove. Slide the old cabin filter frame out carefully to avoid any accumulated debris from being spread around and remove the cabin air filter from the frame.

4. Insert the new cabin filter into the frame making sure it faces to the correct air flow direction and slide it in into the housing. Refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz