

1. The cabin air filter is located behind the glove box compartment.

2. Open the glove box on the passenger side identify the shelf partition inside the unit. Hold the shelf and remove.

3. Behind the shelf is a an opening to access the cabin air filter housing.

4. Unclip the housing lid and slide out the old cabin air filter carefully to avoid any accumulated debris from being spread around.

5. Slide in the new filter making sure it faces the correct air flow direction and refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz