

1. The cabin air filter is located in the centre console behind the lower trim in the passenger footwell area.

2. For better working space, slide the passenger seat all the way back. Remove the lower side trim of the centre console to access the cabin air filter housing. Note: some trim are secured by two bolts, others are just clips.

3. Remove the housing lid by undoing the bolt at the bottom and sliding it out.

4. Slide out the old cabin air filter carefully to avoid any accumulated debris from being spread around.

5. Slide in the new filter making sure it faces the correct air flow direction and refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz