

1. The cabin air filter is located behind the glove box compartment. The glove box is required to be partially removed to gain access.

2. Open the glove box on the passenger side and from both top corners apply pressure towards the inside to bypass the retaining lugs. Once bypassed the lid will drop completely.

3. Identify the cabin air filter housing and unclip the lid from one of the corners and remove.

4. Slide out the old cabin air filter carefully to avoid any accumulated debris from being spread around.

5. Slide in the new filter making sure it faces the correct air flow direction and refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz