

1. The cabin filter housing is located in the engine bay sitting right below the windscreen in a separate compartment attached to the cowl.

2. Once compartment is identified, remove the seal surrounding it on the top edge. With the seal off remove the plastic mesh cover by pulling it towards you. Notice there are two 7mm bolts, one in each side on the outside of the compartment. Remove both.

3. There is another trim cover sitting above the compartment that needs to come off. Simply pull it out from one corner and slide it out.

4. The two cabin filters can be seen now. Gently pull the compartment that was attached with the bolts to allow for space and reach the filters.

5. Remove old filters, clean compartment of any accumulated debris and fit in new set of cabin filters. Refit all components in reverse order.

Ryco Group Pty Ltd 29 Taras Ave Altona North Victoria 3025 Australia. www.rycofilters.com.au RYCO Group A division of GUD NZ Holdings Ltd 626A Rosebank Road Avondale Auckland, New Zealand www.ryco.co.nz