


RYCO FILTERS



FITTING INSTRUCTIONS FOR RYCO CABIN FILTER RCA250P. HONDA CRV RD7



1. The cabin air filter is located behind the glove box compartment unit.
2. Open the glove box and remove the retaining lugs on each top corner. From the inside push the retaining lugs with your finger to unhinge it and remove them.
3. The cabin air filter housing is located above the blower fan. Identify the housing and proceed to unclip the housing lid.
4. Grab the first filter and slide it out slowly to avoid any accumulated debris being spread around. Slide the second filter to one side and then pull out in the same way as the first filter. Clean the area of any debris or dust.
5. Slide in the new filters making sure they face to the right air flow direction and refit all components in reverse order.

GUD Automotive Pty Ltd
29 Taras Ave Altona North
Victoria 3025 Australia.
www.rycofilters.com.au

GUD Automotive -
A division of GUD (NZ) Holdings Limited
626A Rosebank Road Avondale
Auckland, New Zealand
www.ryco.co.nz